

Valve Replacement Instructions

(valid for all aerobed® products)



TIP:

If you are experiencing difficulty replacing your valve because the soft black valve is too stiff, you may warm the flange with a standard household hairdryer. The vinyl will warm and soften after just a few minutes. Do not place the hairdryer too close to the product. This may cause damage. **DO NOT USE A HEAT GUN.** This may damage your product.

Place your thumb on the tab and your index finger underneath the valve lid. Squeeze tab away from hinge to release (Figure 1). Once tab clicks open, easily lift tab cover to open position.

The valve will open as shown (Figure 2).

To remove old valve, at tab latch, peel soft black rim back and lift the hard black plastic on the outer edge of the valve toward the center (Figure 3). The valve will then be easy to lift off. Now you are ready to install the replacement valve (Figure 4).

To install your new valve, first open the replacement valve top. (Figure 1). Once open, seat the hinge area onto the hinge support, then squeeze the soft vinyl ring towards the center of the mattress opening. Simply feed the vinyl through the opening of the new valve. Do not use any tools or sharp objects as this may damage the flange or puncture the product. Once the vinyl has been fed through the opening, make sure there are no bulges in the vinyl ring. Slide your thumb around the inner edge to make sure that it is smooth. Next, lock your replacement valve shut. You are now ready to inflate your Aerobed.




Figure 1




Figure 2




Figure 3




Figure 4

If you have any problems or questions,
please call our Customer Service Department at (888)462-4468.